

M27T20 Firmware Upgrade Tutorial

Machines whose firmware version number starts with 2(EX2.0.1)

Risk warning: Upgrading the firmware may cause color deviation and abnormal display. KTC official does not recommend that you upgrade by yourself.
But we still provide firmware upgrade package and correct upgrade tutorial. **Upgrade at your own risk.**


Notice:

1. Please check first to make sure the version can be upgraded;
2. Do not cut off the power during the upgrade process;
3. The data in the factory menu are display parameters, please do not modify, otherwise it will affect the display effect of the display
4. The U disk format is recommended to use FAT32.



1. Open the OSD menu, check the firmware version number in the lower right corner,

Only machines whose firmware version number starts with "2" can be upgraded, to confirm whether the upgrade conditions are met;




2. Rename the firmware upgrade file to MERGE.bin and put it in the root directory of the U disk; (name must be MERGE.bin)



3. Insert the U disk into the USB socket near the power interface;



4. Turn on the monitor to open the OSD menu:
System settings→USB upgrade→right click to Confirm



5. "Upgrading" appears in the middle of the monitor screen;wait for the upgrade to complete

This process takes about 2-3 minutes, please do not cut off the power during this period;

(There is a small probability that you will not enter the upgrade program after confirmation, you can repeat the third step)



6. After the upgrade is complete, wait for the monitor to display the screen
Need to unplug the power and then power on again



7. After the monitor displays the picture normally, press the middle button of the remote sensor to call out the factory menu; select Reset with the joystick up, and right click to confirm.

